

Please visit our website for more information and to purchase accessories and Matchless E-Liquids available as:

RED - Full strength (24mg) tobacco flavour

BLUE - Medium (18mg) tobacco flavour

LOW - Low strength (12mg) tobacco flavour

MINT - Medium (18mg) mint flavour

CHERRY - Medium (16mg) cherry flavour

VANILLA - Medium (16mg) vanilla flavour

www.matchlessecig.co.uk

 **MATCHLESS** electronic cigarettes

Premium E-Cig Kit

Operating Instructions



VERY TOXIC



NOT FOR SALES TO UNDER 18'S

KEEP OUT OF REACH OF CHILDREN AND PETS
TOXIC BY INHALATION, IN CONTACT WITH SKIN
OR IF SWALLOWED

CE



NOT SUITABLE FOR PREGNANT OR BREASTFEEDING
WOMEN



BATTERY MAY EXPLODE IF CHARGED INCORRECTLY OR
EXPOSED TO WATER, FIRE OR HIGH TEMPERATURE

*Welcome to the world of Matchless
and our Premium E-Cig kit*

KIT CONTENTS



- 2 Rechargeable 650mAh batteries
- 1 Clearomiser glass chamber with coil
- 1 Spare coil
- 1 USB charger
- 1 lanyard
- 1 bottle RED E-liquid 10ml
- 1 bottle BLUE E-liquid 10ml
- 1 Carry case

ACTIVE CONTENTS

Matchless E-liquid contains Nicotine, Propylene Glycol, Glycerol and flavourings.
Nicotine has been shown to be addictive

DIRECTIONS

The 2 batteries supplied require charging before use. To charge, screw a battery into the usb charger and the charger into a usb slot. When the battery is fully charged it will flash quickly several times.

To fill, unscrew coil from clearomiser and drip Matchless E-Liquid up to 2.0ml into the glass chamber from the large open end, taking care NOT to get any in central glass tube. Screw coil back on and attach to battery

To use hold down button on battery and inhale.

Safety feature - to lock battery in off position click button quickly 5 times (and light will flash several times). Repeat 5 times to switch on.

To clean clearomiser, rinse in warm water.

Note battery life is around 300 charges before it needs replacing. Coils will also need changing periodically .